

E-204L Chassis with IS-760R2UP Power Supply


Installation Guide



1. Remove motherboard plate. Refer to step 8 for more details.



2. Remove single power supply bracket




3. Remove power supply's brackets from both sides




4. Remove power supply reset button



5. Install power supply brackets come with chassis





6. Install power supply rear bracket comes with power supply



7. Install power supply reset button to the chassis



8. Install power supply housing. Place and tilt the power supply housing inside the chassis with slanted angle to let the housing get through the opening of chassis rear panel



9. Secure power supply on both sides and the one at cable side from bottom

10. Finish

